

### BNC Connectors



#### RG6 INLINE

MODEL	DESCRIPTION
183-006-1	RG6 BNC Male Crimp
183-006-10	RG6 BNC Male Crimp, Pkg/10
V399B-SNS-GOLD	RG6 BNC Male Crimp - Compression, Gold

#### RG59 INLINE

MODEL	DESCRIPTION
183-759-1	RG59 BNC Female Crimp
183-059-1	RG59 BNC Male Crimp
183-059-10	RG59 BNC Male Crimp, Pkg/10
183-259-1	RG59 BNC Male Solder Clamp
183-159-1	RG59 BNC Male Twist-On
183-159-10	RG59 BNC Male Twist-On, Pkg/10
V399/SNS	RG59 BNC Male Crimp - Compression



#### RG58

MODEL	DESCRIPTION
183-758-1	RG58 BNC Female Crimp
183-058-1	RG58 BNC Male Crimp
183-058-10	RG58 BNC Male Crimp, Pkg/10
183-258-1	RG58 BNC Male Solder Clamp
183-158-1	RG58 BNC Male Twist-On
183-158-10	RG58 BNC Male Twist-On, Pkg/10



#### CHASSIS MOUNT

MODEL	DESCRIPTION
183-510-1	BNC Female
183-510-10	BNC Female, Pkg/10
183-515-1	BNC Female with Flange
183-520-1	BNC Female, Isolated

### PAL Connectors



MODEL	DESCRIPTION
188-750	PAL Female Solder
197-020	PAL Female to F-Male Adapter
188-050	PAL Male Solder
198-005	PAL Male to F-Female Adapter

### F - CATV Connectors

**New!**



#### RG6 INLINE

MODEL	DESCRIPTION
187-156-10	RG6 F-Male Crimp Integral Ring, Pkg/10
187-156-100	RG6 F-Male Crimp Integral Ring, Pkg/100
187-056-10	RG6 F-Male Crimp, Pkg/10
187-056-100	RG6 F-Male Crimp, Pkg/100
V356/SNS-1	RG6 RCA Male - Compression
F56QSN5W	RG6 Compression - Quad Shield
89-055	RG6 Compression, Pkg/50



#### RG59 INLINE

MODEL	DESCRIPTION
187-159-10	RG59 F-Male Crimp Integral Ring, Pkg/10
187-059-10	RG59 F-Male Crimp, Pkg/10
187-059-100	RG59 F-Male Crimp, Pkg/100



#### JOINERS

MODEL	DESCRIPTION
187-781-10	F-Female to F-Female, Pkg/10
187-781-100	F-Female to F-Female, Pkg/100
187-250	F-Female to F-Male Push-on
187-250-10	F-Female to F-Male Push-on, Pkg/10



#### CHASSIS MOUNT

MODEL	DESCRIPTION
187-561-10	F-Female, Pkg/10
187-561-100	F-Female, Pkg/100

### N Connectors



MODEL	DESCRIPTION
184-515-1	N Female Chassis Mount with Flange
184-058-1	N Male Crimp RG58
184-258-1	N Male Solder RG58
184-208-1	N Male Solder RG8

### RF Adapters



#### BNC

MODEL	DESCRIPTION
193-300-1	BNC Female to 2 BNC Females
378-130	BNC Female to Banana Plugs
193-210-1	BNC Female to BNC Female
193-210-10	BNC Female to BNC Female, Pkg/10
193-215-10	BNC Female to BNC Female Chassis, Pkg/10
197-010-1	BNC Female to F Male
194-005-1	BNC Female to N Male
191-010-1	BNC Female to RCA Male
191-010-10	BNC Female to RCA Male, Pkg/10
195-005-1	BNC Female to TNC Male
192-015-1	BNC Female to UHF Male
378-120	BNC Male to 2 Binding Posts
193-305-1	BNC Male to 2 BNC Female
193-305-10	BNC Male to 2 BNC Female, Pkg/10
193-205-1	BNC Male to BNC Female R/A
193-200-1	BNC Male to BNC Male
193-005-1	BNC Male to F Female
193-005-10	BNC Male to F Female, Pkg/10
193-025-1	BNC Male to N Female
193-010-1	BNC Male to RCA Female
193-010-10	BNC Male to RCA Female, Pkg/10
193-011-1	BNC Male to RCA Female Gold
193-011-10	BNC Male to RCA Female Gold, Pkg/10
193-015-1	BNC Male to UHF Female

#### F



MODEL	DESCRIPTION
191-005-1	F Female to RCA Male
191-005-10	F Female to RCA Male, Pkg/10
197-005-1	F Male to RCA Female

#### N




MODEL	DESCRIPTION
194-210-1	N Female to N Female
192-020-1	N Female to UHF Male
194-305-1	N Male to 2 N Females
194-010-1	N Male to UHF Female

#### UHF

MODEL	DESCRIPTION
195-010-1	UHF Female to TNC Male

### TNC Connectors



MODEL	DESCRIPTION
185-520-1	TNC Female Chassis RG58
194-058-1	TNC Male Crimp RG58
194-059-1	TNC Male Crimp RG59
194-158-1	TNC Male Solder RG58